



1. Polyroof 185 membrane
2. Support Batten
3. Drip Trim

**NOTES**

- a. The drip trim should not sit tight against the fascia.
- b. It may be prudent to incorporate a dpc or similar between the fascia and the drip trim. The dpc should be nailed to the plywood and dressed into the gutter to provide a secondary seal.



Polyroof Products Limited  
 Furness House  
 Castle Park Industrial Estate  
 Flint  
 Flintshire  
 CH6 5XA

Tel : 01352 735 135  
 Fax : 01352 735 182  
 email : technical@polyroof.co.uk  
 web : www.polyroof.co.uk

Reference

**Fig 2.10**

Title

**Drip Detail**

Scale

**N.T.S.**

Drawn By

**S.H**

Date

**24/11/2008**

**Polyroof 185 System**