



1. Drip Trim
2. All ply mechanically fixed
3. Right angle trim ( lip removed from drip)
4. Re-inforced with extra layer of base and mat
5. Tile and felt
6. Kick board either laid direct to ply or flat trim mechanically fixed
7. Fillet trim

**Notes:**

It may be possible to create the detail using Special or Non-Standard trim profiles. This may prove to be more economic, but will be dependant on the size and shape of the gutter.



Polyroof Products Limited  
 Furness House  
 Castle Park Industrial Estate  
 Flint  
 Flintshire  
 CH6 5XA

Tel : 01352 735 135  
 Fax : 01352 735 182  
 email : technical@polyroof.co.uk  
 web : www.polyroof.co.uk

Reference  
**Fig 2.12**

Title  
**Box Gutter Detail**

Scale  
**N.T.S.**

Drawn By  
**S.H**

Date  
**24/11/2008**

**Polyroof 185 System**