



1. Polyroof 185 Membrane
2. 18mm Metsä Spruce (II/III) Plywood
3. Timber Batten
4. Drip Trim
5. Glidevale FV250 Ventilator
6. Ventilated Airspace Min 50mm
7. Glidevale FV250 Gutter Spacer
8. Gutter
9. Fascia

NB

FV250 to be installed behind gutter to allow ventilation behind gutter.

FV250 spacer to be used to set gutter off fascia board.



Polyroof Products Limited
 Furness House
 Castle Park Industrial Estate
 Flint
 Flintshire
 CH6 5XA

Tel : 01352 735 135
 Fax : 01352 735 182
 email : technical@polyroof.co.uk
 web : www.polyroof.co.uk

Reference
Fig 2.88

Title
Ventilated Drip - Cold Roof Design

Scale
N.T.S.

Drawn By
P.A.

Date
03/01/2013

Polyroof 185 System