



1. Protec System - taken into chase
2. Timber Fillet
3. Substrate

On completion - the detail should be re-pointed or finished with PU sealant.

As an alternative the system may also be flashed with lead or GRP.

Care must be taken positioning the flashing with regard to any cavity tray.

Timber fillet may be omitted by double taping right angle.

It is advised that wall flashings are periodically inspected.

For further guidance please contact Polyroof Technical Services.



Title: Wall Abutment Detail (Chase)

System: Protec

Ref: 3.06

Scale: NTS
(Do Not Scale From Drawing)

Drawn: OM

Date: 01/10/15