



1. Independent Flashing (Lead or Similar)
2. Protec System
3. Timber Fillet
4. Substrate

On completion - the detail should be re-pointed or finished with PU sealant.

Care must be taken positioning the flashing with regard to any cavity tray.

It is advised that wall flashings are periodically inspected.

Flashings are not covered by the Polyroof Guarantee.

For further guidance please contact Polyroof Technical Services.



Title: Wall Abutment Detail (with Independent Flashing)

System: Protec

Ref: 3.52

Scale: NTS
(Do Not Scale From Drawing)

Drawn: OM

Date: 01/10/15