



1. Weathering flange / seal
2. Elastex membrane
3. Re-inforced with Elastex Taping Mat

**Notes:**

- a. Right angle to be strengthened by double taping. Note - disbondment tape may be required for any protrusions liable to significant movement.
- b. Pipe must be abraded, solvent wiped and where required primed in accordance with the Polyroof coatings manual
- c. A flashing detail should be created with a weathering flange/seal. It should be noted that flashing details are not covered by the Polyroof guarantee.
- d. This detail may also be used for other small protrusions. Consult Polyroof Technical Services for advice.



Polyroof Products Limited  
 Furness House  
 Castle Park Industrial Estate  
 Flint  
 Flintshire  
 CH6 5XA

Tel : 01352 735 135  
 Fax : 01352 735 182  
 email : technical@polyroof.co.uk  
 web : www.polyroof.co.uk

Reference  
**Fig 4.11**

Title  
**Pipe / Protrusion Detail**

Scale  
**N.T.S.**

Drawn By  
**C.S.**

Date  
**10/02/2009**

**Elastex System**