



ColdLay Kit

NatraTex ColdLay kits are supplied in a sealed 25kg bucket with a small tin of Clear Cold Seal paint.

The following guidelines relate specifically to our ColdLay kits, which are designed for small repairs in NatraTex, where the repair area is not trafficked by vehicles. Such as around bollards, signposts etc.

- The installation area should be of sufficient depth, have a sound and suitable substrate to accept a minimum of 25mm compacted depth of the new NatraTex ColdLay.
- Vertical joints should be cut (if possible) with a Stihl type saw to provide a sound clean edge, the area should be dry and swept clean of any loose debris, prior to application.
- The Clear Cold Seal Paint is brush applied to the vertical face of the area to be reinstated.
- The NatraTex ColdLay should then be applied to the area and compacted with vibroll or suitable equipment.
- Do **NOT** apply Clear Cold Seal paint as over-banding or to the exposed NatraTex surface course, it is only for sealing between vertical joints to eliminate water ingress.
- Once compacted the installation is complete and the area should be isolated from use for 12 hours minimum, preferably 24 hours to ensure full cure.
- If you are unsure or need specific guidance on application or suitability please contact our sales office on 01594 826768 or email enquiries@natartex.co.uk