



Following the installation and adjustment of the closer the cover is fitted as follows:-

- 1) Places the 2x 5mm nylon spacers over the M5 tapped holes closet to the door face



- 2) Slide the cover over the closer body ensuring the 5mm nylon spacers are positioned over the M5 tapped holes



- 3) Secure the cover to the closer body using 2x M5 x 8mm Dome Head Screws with a 3mm allen key



GEZE UK Ltd ,  
Blenheim Way,  
Fradley Park,  
Lichfield,  
Staffordshire,  
WS13 8SY

[www.geze.com](http://www.geze.com)  
TEL 01543 443000  
FAX 01543 443001